



Propresenter Computer Updates

Most of our presentation installs use the same software and peripherals. Updating usually requires multiple steps so be sure to check all of these.

1. Upgrade ProPresenter to the latest stable version (Currently 21.0.1). Do this from within the ProPresenter software
2. You will need to be running the latest version of MacOS (Currently MacOS Tahoe 26.4). If you are not currently on Tahoe, DO NOT not update your MacOS until after you have updated ProPresenter
3. You will need to upgrade BlackMagic Desktop Video to 15.3 ([Link for Blackmagic download](#))
4. You will need to upgrade the DisplayLink software ([Link for DisplayLink Download](#))